

# Benzapon Pre

## Pre-brushing agent



### Properties

- adapted to the special requirements of KW solvents
- prevents graying and has a high water-binding capacity
- easy to rinse out in KW solvent

### Application

Benzapon Pre is brushed pure onto the soiled areas of the textiles.

When using the Jet-Clean technology, the product must be diluted with the solvent used (KWL or SENSENE®) (1:5). When using water in the pre-spotting process, ensure that there is a sufficient base concentration of cleaning booster in the liquor to prevent localized greying. Pre-spotted garments should be cleaned in the machine after a maximum of 30 minutes exposure time. Much longer exposure times can lead to material damage.

Take care when using on delicate fabrics. In case of doubt, especially if color fastness is suspected, a hem test should be carried out.

### Technical data

Density (20°C)	pH-value
0,81 kg / l	7

### Notes

KWL strongly degreases the skin, which can lead to allergic reactions. We recommend wearing protective gloves when brushing with brushing solutions containing KWL. Store in a cool and closed place

For commercial use only. This leaflet is for non-binding information only. The information is based on our current knowledge and experience. In any case, the user is obliged to carry out his own tests and trials to check the suitability of the products for his intended processes and purposes. The information in this leaflet does not constitute a guarantee for the quality and durability of the goods to be supplied by us. We reserve the right to make technical changes within the scope of what is reasonable. The current version of the corresponding EU safety data sheet must also be observed.