

Lizerna Desize

Desizing agent

Properties

- enzymatic desizing
- highly effective and very economical
- reduces sizing distortions (crow's feet)
- uniform fabric appearance

Application

Lizerna Desize is used for the enzymatic removal of natural sizing when washing new textiles in industrial laundry processes.

The product reduces and removes existing sizing-related distortions and tensions in the fabric (crow's feet) and thus ensures a uniform fabric appearance.

It is used in a two-bath process in combination with a detergent and an alkali booster.

Sample application:

Prewash:

Time: 6 minutes

Temperature: 40°C

Products: 1g/kg Ozerna Polar

8g/kg Element A

5g/kg Lizerna Desize

Main wash:

Time: 11 minutes

Temperature: 70°C

Products: 2.5g/kg Lizerna Desize

Dosing

Desized

Concentration 2,5 - 5,0 g / kg dry laundry

Temperature 40 - 70 °C

Exposure time 5 - 15 min.

Addition in combination with alkali booster and colored/fine detergent

Technical data

Density (20°C)

1,25 kg / l

Notes

Storage:

Store the product only in the original container and secured frost-free between +5 and +40°C. Avoid direct sunlight. After removing partial quantities, please close the container tightly again.

For commercial use only. This leaflet is for non-binding information only. The information is based on our current knowledge and experience. In any case, the user is obliged to carry out his own tests and trials to check the suitability of the products for his intended processes and purposes. The information in this leaflet does not constitute a guarantee for the quality and durability of the goods to be supplied by us. We reserve the right to make technical changes within the scope of what is reasonable. The current version of the corresponding EU safety data sheet must also be observed.